

# Multi Function Kiosk For Deposit

The AIG Deposit Kiosk, a Self Service Terminal developed to allow deposit of a batch of checks in a simple, secure and quick way. The AIG Deposit Kiosk has an internal document processing module providing image capture and check reading. The kiosk is ergonomically designed with a minimum footprint and attractive line; it fits ideally into a bank's lobby environment.

The customer is offered the capability to deposit multiple checks, in a very short time, thanks to a high transport speed and short scanning time, up to 30 checks at a time can be fed. The customer follows the instructions displayed on monitor and lighting indicators. The documents are automatically aligned during feeding.

The kiosk prints a receipt with all the images of deposited checks as a proof of completed operation.

## Features

- Document Processing Module for depositing checks & pay - in forms
- Automatic storage of all code lines and check images
- Deposit transaction collected in real time by the bank
- Account number and total deposited amount recording and saving
- A bar code reader to identify payment utility bills
- Easy access to all internal components
- User friendly TFT 12,1" LCD monitor with touch screen
- Thermal printer 80mm or (optionally) A4 size
- Stainless steel keypad w/encryption - 12 numeric + 4 function keys
- Connectable to the bank's in branch security alarm system
- A security locked compartment for processed checks storing
- Possibility to encrypt/decrypt messages to/from host
- Cabinet can be anchored to the floor if required

## Technical Specifications

### INTERNAL MODULES:

#### DOCUMENT PROCESSING MODULE

- Module for checks and pay-in documents reading and scanning
- High transport speed (0,71 mt/sec) and very short scanning time
- On board image compression
- Void/endorsement, Escrow function (single & multiple), sorting (4 pockets)

#### LCD MONITOR

- TFT 12,1" color SVGA for high resolution graphics

- Capacitive touch screen

#### CUSTOMER KEYPAD

- Stainless steel 130 x 110 mm with 12 numeric + 4 function keys
- Data Encryption (Triple DES Standard) as option

#### CARD READER

- Manual – handles only magnetic strip
- Motorised – hybrid (magnetic+chip card), shutter, EMV /2 standard (option)

#### RECEIPT PRINTER

- Thermal printer for 80 mm or, optionally, A4 format
- Transaction details printouts available in any language or fonts
- Single/multiple check images and advertising logos available
- Printer status report

#### BAR CODE READER

- For payment utility bills (option)

#### PERSONAL COMPUTER

- Secured PC base unit with standard configuration (option)

#### UPS UNIT

- Available as option

### INTERFACE

Ethernet LAN Connection to the host



Kiosk dimensions	
height	54.6 in.
width	20.28 in
depth	25.74 in.
weight	176 Lb.

Document size	
height	2.36 - 4.33 in.
length	4.92 - 8.66 in.
weight	18 -26 lb.
paper thickness	.0035 -.0055 in

### KIOSK CABINET:

- Support anchoring to the floor
- Robust and tamper resistant to minimize vandal attack
- Restricted access of supervisor function reserved only for authorized staff
- Locked compartment to store checks – removable as a closed box

### TECHNICAL CHARACTERISTICS:

- Voltage: 230 VAC (50Hz) - 115 VAC (60Hz)
- Power consumption: 70 VA
- Operating temperature range: 15° to 40° C
- Humidity (storage): 5 to 90% non-condensing
- Humidity (when operating): 20 to 80% non-condensing



East Coast:  
1304 SW 160th Ave. Ft. Lauderdale FL 33326  
(954) 748-9222 Fax (954) 747-3666

West Coast:  
26941 Cabot Rd. #122 Laguna Hills, CA 92653  
(949) 215-0638 Fax (720) 596-3045

Compliance:  Safety: EN60950

www.andersonimaging.com  
info@andersonimaging.com